

ENDURA SUPPLY

Olaer Product List

- Part No: 03GA00136
- Part No: 091590/01188
- Part No: 092390-011S1
- Part No: 100100-00220
- Part No: 104716-00020
- Part No: 108374-01125
- Part No: 108496-01125
- Part No: 108654-01125
- Part No: 108657-01125
- Part No: 108666-01125
- Part No: 109099-01125
- Part No: 109100-01125
- Part No: 109847-01125 100-7315-503-611
- Part No: 110.444-00225 SPARE BLADDER 32L (EHV 32-330)
- Part No: 110298-00220
- Part No: 110444-00225
- Part No: 110618-00225
- Part No: 14515.
- Part No: 190290-00225
- Part No: 190362-00225
- Part No: 190542-00225
- Part No: 1HV32.330/05 GD
- Part No: 202182-07733
- Part No: 30236566
- Part No: 30236567
- Part No: 30236767
- Part No: 30236768
- Part No: 30236773
- Part No: 42C/99 IHV32 1100MM
- Part No: 92700GLOMB-S
- Part No: 947719
- Part No: AF5266PM300/A.

- Part No: AIR VALVE (SPARE FOR ITEM 1)
- Part No: B120T-60
- Part No: B25-80 05T0021
- Part No: BLADDER (SPARE FOR ITEM 1) a “ COMPLETE
- Part No: BLASE 32 L
- Part No: BLEEDER AND SEAL
- Part No: BN210-14A
- Part No: BN350-025 40-50 BAR
- Part No: CE-ASME-CRN 10-40/90 G3"1/2 PTFE-EBV 10/40
- Part No: COMPLETE FLUID PORT
- Part No: DI 20 MS/3/330 CH
- Part No: DI10EYS2330CV24VCC
- Part No: DI10MS/2/350CH
- Part No: DI20MS/2/330CH
- Part No: DI20MS/3/210CH
- Part No: DI32MS/3/330CH
- Part No: EBV 20-40/90-40-AA25-48-002
- Part No: ECA-12-01-L-N
- Part No: ECA-20-01-L-N
- Part No: ECA20-01-L-N
- Part No: EHV 1 - 350/90 01125
- Part No: EHV 10-330 D22 SPARE KIT
- Part No: EHV 10-330 A~22
- Part No: EHV 10-330/90
- Part No: EHV 10-480/90
- Part No: EHV 12-330/90-330-AA25-13-002
- Part No: Typ EHV 1-350/90
- Part No: EHV 2,5.350/90
- Part No: EHV 2,5-690/90-690-AA25-1A-002
- Part No: 10854701125
- Part No: 108371-01125
- Part No: EHV 20-330/90-330-AA25-13-002 REF. 108655-01125
- Part No: EHV 2-5-350 D22 SPARE KIT
- Part No: EHV 32-330 ACCUMULATOR
- Part No: EHV 32-330 D22 SPARE KIT

- Part No: EHV 4-350/90-350-AA25-12-002 REF. 108661-01125
- Part No: EHV 50-330 D22 SPARE KIT
- Part No: EHV 5L 690/90
- Part No: EHV F 50.330/90
- Part No: EHV1-350/90
- Part No: EHV32-250-330
- Part No: EHV-32-250-330-TUV
- Part No: EHV-32-330 P/N 108373-01125
- Part No: EHV32-330/90
- Part No: EHV32-330/90 10837301125
- Part No: EHV 5-330/90
- Part No: EHV F 10-330 D22 SPARE KIT
- Part No: EHV F 20-330 D22 SPARE KIT
- Part No: EHV F 24,5-330/90,30236565
- Part No: EHV F 24.5-330 D22 SPARE KIT
- Part No: ELM0.75-350/00/AF 01102
- Part No: EMO 08 BM1B
- Part No: EMO 16 BM1B
- Part No: EMO 60
- Part No: ERA32NME
- Part No: ERA40NME
- Part No: FTD.22-D30043
- Part No: GAS VALVE
- Part No: GAS VALVE TYPE C
- Part No: GASKET (SPARE FOR ITEM 1)
- Part No: GR70 SMT16B800L RF3
- Part No: GX6P
- Part No: IBV 20-70/01
- Part No: IBV/EBV 2-5-80/90-350-AA25-12-002
- Part No: IBV/EBV-5-80/90-80-AA25-43-002
- Part No: IBV20 7001
- Part No: IHV 20-330/94
- Part No: Accu Ballone For IHV 24,5-250/300
- Part No: IHV 24,5-250/330
- Part No: IHV 32-330/90-330-AA25-13-002

- Part No: IHV-20-250 obsolete
- Part No: IHV4-330/05
- Part No: K45-70 - OBSOLETE, REPLACED BY PWO B120-70
- Part No: K45-70 - OBSOLETE, REPLACEMENT PWO B120-70
- Part No: KIT EHV-20-330/90
- Part No: LAC2-011-4
- Part No: M0119912.01
- Part No: M35-CC F 00
- Part No: OAYB1
- Part No: OAYB2,5
- Part No: OLG 0,13-50/00-50-RF 25-61-000
- Part No: OLM 0,5-210/00-210-AA40-29-004
- Part No: OLM 0,75-350/00
- Part No: OLM 1,0-210/00-210-AA25-20
- Part No: OLM0,5-210/00-210-AA25-29
- Part No: P/N 05T0375
- Part No: P/N 190291-00225 FOR EHV-32-330(108373-01125)
- Part No: P/N UCK-03-06
- Part No: PLATE-COOLER B10-40
- Part No: PWO
- Part No: PWO B10 - 30
- Part No: PWO B120-40
- Part No: PWO B120-60
- Part No: B120T-70 (AnschlAsse: 2 x G 1 1/2" Innengewinde 2 x G 1 1/4" Innengewinde Mit Gewindebolzen Ref : 05T0484)
- Part No: PWO B45-120
- Part No: PWO B5-20
- Part No: PWO B8-20 obsolete, replaced by O5T0457
- Part No: PWO TYP 111097182007851
- Part No: PWO-B45-60
- Part No: PWOK5-20
- Part No: QEGO 07-04-0,75-20-E
- Part No: QEGO 16-4-1,5-60-E
- Part No: REC EHV 4-350
- Part No: REF. FTD.021-3-10211000
- Part No: REF. FTD.21-D30084

- Part No: REF. 110441-00225
- Part No: REF. 110618-00225
- Part No: REPAIR KIT FOR EHV F 50.330/90
- Part No: REPAIR KIT FOR EHV-5-350
- Part No: SDC-026-B-0-000-DHG-0-0
- Part No: SNAP RING
- Part No: TYPE:ELM 0,75-210/00-210-1125-20 108497-01125 ACCUMULATOR
- Part No: VG3 250 1 TS 2 0 1
- Part No: VG3 400 1 TS2 1 OLD VERSION
- Part No: VG3 battery charger set
- Part No: VGU/25/250.7.TS3.3
- Part No: (20214122723) VGU/F.25/250.7.TS2.3
- Part No: B5T-10 (AnschlAsse: 2 x G 3/4" Innengewinde 2 x G 1/2" Innengewinde)
- Part No: WEG03
- Part No: LHC-044-A-00-S50-0-0 (A-I/LuftkAhler)
- Part No: IHV 10-330/90 alte Bezeichnung/neues Bezeichnung EHV 10-330/90-K
- Part No: GasfAllung 36 bar
- Part No: 10607
- Part No: 5056262 - obsolete, replaced by LOC3-016-4-D-D-0-00-000-0-0-0-0
- Part No: LOC3-016-4-D-D-0-00-000-0-0-0-0
- Part No: 540SA-02
- Part No: 108669-01125
- Part No: IHV 12-330/90-GD
- Part No: IHV 12-330/90-GD Gland ring
- Part No: IHV 12-330/90-GD Ring nut
- Part No: IHV 12-330/90-GD Venting screw with gasket
- Part No: IHV 12-330/90-GD Fluid port sub-assembly
- Part No: IHV 12-330/90-GD Set of gaskets
- Part No: IHV 24-330/90-GD Anti-extrusion ring/washer
- Part No: IHV 24-330/90-GD Gland ring
- Part No: IHV 24-330/90-GD Ring nut
- Part No: IHV 24-330/90-GD Venting screw with gasket
- Part No: IHV 24-330/90-GD Fluid port sub-assembly
- Part No: IHV 24-330/90-GD Set of gaskets
- Part No: IHV 32-330/90-GD Anti-extrusion ring/washer

- Part No: IHV 32-330/90-GD Gland ring
- Part No: IHV 32-330/90-GD Ring nut
- Part No: IHV 32-330/90-GD Venting screw with gasket
- Part No: IHV 32-330/90-GD Fluid port sub-assembly
- Part No: IHV 32-330/90-GD Set of gaskets
- Part No: EHV 24-330/90
- Part No: EHV 10-330/90-K
- Part No: VG3-25-1-TS3-1-1 obsolete replacement VG U-25-TS3
- Part No: VG U-25-TS3 (202182-03733)
- Part No: 190290-00280
- Part No: IHV 24-330/90GD
- Part No: IHV 32-330/90GD
- Part No: 1522010880
- Part No: 1035540429
- Part No: CONNECTOR MG 2-F G A BSP ITEM 21 for IHV 37-390
- Part No: DI 10 EYS 2-330-BH-24VDC-000 Obsolete, replaced by DI10EYS2350CH24VCC
- Part No: 10845401125
- Part No: DI10MS Obsolete, replaced by DI10EYS2350CH24VCC
- Part No: RHD-10S
- Part No: DI10EYS2350CH24VCC.
- Part No: PWO K45-80
- Part No: K45-70
- Part No: PWO K16-20
- Part No: 202515-03648
- Part No: 999932-03650
- Part No: 19029900225
- Part No: 19029100225
- Part No: EHV20L-330B/90
- Part No: 10383101125
- Part No: B10THX54
- Part No: EHV/5 LTS
- Part No: EHV 12-330/90 D22.5
- Part No: EHV 12-330/90,
- Part No: 19029800225
- Part No: 20138102121 Type: VG3.10.1.TS2.1

- Part No: EBV 10/40 TEFLON 8,5 CE-ASME-CRN
- Part No: 19043900250
- Part No: VGU/F.25/250.8.TS2.3
- Part No: EHV 50 250-330 D.50 (19029200225)
- Part No: Impermeability Kit For IHV 24,5-250/300
- Part No: Accu Port For IHV 24,5-250/330 Obsolete, replaced by ACUM EHV 24,5L - 330B/90 AMIX25
- Part No: 109848-01125 replaced by 10984801125
- Part No: ACUM EHV 24,5L - 330B/90 AMIX25
- Part No: 19029200225
- Part No: 110767-01125
- Part No: Balloon: F1801 110671-05200
- Part No: O-RING 54X3 ITEM 22 for IHV 37-390
- Part No: CONNECTOR ASSY ITEM 20 for IHV 37-390
- Part No: SEAL ITEM 18 for IHV 37-390
- Part No: LOCK NUT ITEM 16 for IHV 37-390
- Part No: ANTI-EXTRUSION RING ITEM 14 for IHV 37-390
- Part No: O-RING 78.74 X5.33 ITEM 13 for IHV 37-390
- Part No: COMPLETE FLUID PORT ITEM 10 for IHV 37-390
- Part No: GUARD CAP ITEM 9 for IHV 37-390
- Part No: GUARD CAP ITEM 8 for IHV 37-390
- Part No: GAS VALVE ITEM 7 for IHV 37-390
- Part No: BLADDER ITEM 5 for IHV 37-390
- Part No: BLADDER ASSY ITEM 4 for IHV 37-390
- Part No: O-RING 54X3 ITEM 22 for IHV 50-330
- Part No: CONNECTOR MG 2-F G A BSP ITEM 21 for IHV 50-330
- Part No: CONNECTOR ASSY ITEM 20 for IHV 50-330
- Part No: SEAL ITEM 18 for IHV 50-330
- Part No: LOCK NUT ITEM 16 for IHV 50-330
- Part No: ANTI-EXTRUSION RING ITEM 14 for IHV 50-330
- Part No: O-RING 78.74 X5.33 ITEM 13 for IHV 50-330
- Part No: COMPLETE FLUID PORT ITEM 10 for IHV 50-330
- Part No: GUARD CAP ITEM 9 for IHV 50-330
- Part No: GUARD CAP ITEM 8 for IHV 50-330
- Part No: GAS VALVE ITEM 7 for IHV 50-330
- Part No: BLADDER ITEM 5 for IHV 50-330

- Part No: BLADDER ASSY ITEM 4 for IHV 50-330
- Part No: 10837001125
- Part No: IHV20-330/90-330-AA25-13-002
- Part No: 108879-01125
- Part No: 042785011S1 Type: SBV2 ACCU 1-40/13
- Part No: 110671-05200
- Part No: 108547-01125
- Part No: Typ: EHV 32-330/90
- Part No: Typ VG U-250-TS3
- Part No: B5T-10
- Part No: Blase 2,5 l A, 22 VL fAr EHV 2,5-350/90
- Part No: Dichtungssatz zu EHV 2,5-10
- Part No: Blase 10 l A, 22 VLfAr EHV 10-350/90-L
- Part No: LAC 003-2-D-00-000-0-0, Art-Nr. 05P1142
- Part No: F1801
- Part No: EHV 6-350/90
- Part No: Nitrogen press apparatus for EHV50-300
- Part No: Blase 475 l A, 63 VL
- Part No: 19029400225
- Part No: 100345 Obsolete Directly replaced by 111277-00220
- Part No: Ref : OA05A1522
- Part No: Typ EHV 20-330/90
- Part No: LAC2-M-011-4-D-40-S50-0-0
- Part No: 190299-00225
- Part No: Blasenkit 4 Liter
- Part No: EBV 0,5-50/00
- Part No: 102396-01626
- Part No: 106186-00220
- Part No: 105543-00200
- Part No: 108479-01626
- Part No: B10T-30
- Part No: 092594-01225
- Part No: 190449-00225
- Part No: 19043900280 KIT EBV 10-40 D22
- Part No: O5T0457

- Part No: IHV 10 330/.. GD-L old reference, new reference EHV 10-350/90-L-DA
- Part No: EHV 10-350/90-L-DA
- Part No: 10984801125
- Part No: 10984701125
- Part No: Typ VG U-10-TS3
- Part No: 10845901125 Type: EHV 10L-350/90/DA
- Part No: 19054100225
- Part No: NA14-BF unknown, standard version VGU/F.25/250.8.TS3.3
- Part No: VGU/F.25/250.8.TS3.3
- Part No: 5849007203
- Part No: LAC 033-6-B-50-000-0-0
- Part No: 637055V2205 Type: DS307/SCH/V2/5-55/SL/C5